

Important Information for Using Warm.A.Pet Heat Pads

Read through to the end prior to using your heat pad

1/. Bedding

We recommend that your Warm.A.Pet heat pad is placed on 50mm of (flat) bedding material (such as a firm thin mattress or a folded blanket) with 30mm of soft, comfortable bedding on top of the heat pad.

This will provide insulation and generate warmth from the pad. Your pets' weight will also further contribute to the insulating effect.

Note:The element heats from both sides and placing the pad directly on a cold surface will prevent the pad from heating effectively.

Allow several hours for the one heat setting pads to completely warm up when switched on for the first time and, once you are satisfied that the level of warmth is suitable for your pet, leave it on continuously to avoid further " warm-up " delays experienced if switched off and on daily.

(Set Deluxe models on highest setting only to start bed warming process then reduce to medium or low)

2/. Heat Pad Not Warm Enough?

Add more (flat, firm) bedding underneath and/or allow extra time to warm up - remember that your pet will add insulation so check warmth of the pad when your pet has been in bed for a little while.

You may place a weighty soft toy or phone book on top of the bedding to simulate your pets' weight/body mass to check the generation of warmth then remove the object after the heat pad has warmed up effectively.

3/. Heat Pad Too Hot?

Take away some bedding from underneath and make sure that the top bedding is not too thick (just like our own electric blanket extra bedding and weight will generate more heat) or reduce heat setting on Large Deluxe or Voltage setting on Small Deluxe.

* Do Not Permanently Leave Deluxe models on Highest Setting - Over-heating Will Occur.

4/. My Pet Has A Trampoline Bed!

The Warm.A.Pet heat pads (rigid models) may not be suitable to be used on trampoline beds. Ensure the heat pad is placed on a flat, even surface to avoid bending the pad and damaging the internal heating element.

(You may " level up " the tramopline bed surface with a folded blanket if required).

Important: Steps 2/. & 3/. should be noted and actioned prior to reporting non-functioning of the heat pad.

Further assistance, if required, is available by calling your supplier or the manufacturer of Warm.A.Pet heat pads on 03 9544 1471.

Wattage

Large Deluxe:

"HI" Setting = 16 watts (Do not leave on high for too long)

"MED" Setting = 9 watts (Generally ideal setting)

"LO" Setting = 6 watts (Low heat output on this setting)

Large & Small Economy Models : (One Setting) = 9 watts

**Small Deluxe: = 12v, 9v, 7.5v, 6v, 5v, 4.5v, & 3volts (7 watts down to 0.5 watts)